ΑF


## **Modular Type** Filter Regulator Series AW

Filter Regulator Series AW	Model	Port size	Options
	AW10-A	M5 x 0.8	Bracket
	AW20-A	1/8, 1/4	Float type auto drain
	AW30-A	1/4, 3/8	Round type pressure gauge
	AW40-A	1/4, 3/8, 1/2	Set nut (for panel mount)*
P.73 to 84	AW40-06-A	3/4	* For AW20-A to AW40-06-A, panel fitting dimensions are different from those of the current AW series.

## Filter Regulator


# AW10-A to AW40-A

#### **Symbol** Filter Regulator



• Integrated filter and regulator units save space and require less piping.

#### **How to Order**



- Option/Semi-standard: Select one each for a to i.
- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.

  | Alpha | Alp

Example) AW30-03BG-1N-A

#### 

(Refer to pages 81 to 84 for details.)

	_	_							
				Symbol	Description		Body	size	
						10	20	30	40
					Metric thread (M5)	•	_	_	_
		Dia a		-	Rc	_	•	•	
2		Pipe	thread type	N Note 1)	NPT	_	•	•	
				F Note 2)	G	_	•	•	•
$\equiv$				+					
				M5	M5		_	_	
				01	1/8	_		_	_
3			Port size	02	1/4	_		•	
9			FUIT SIZE	03	3/8	_	_	•	
				04	1/2	_	_	_	
				06	3/4	_	_	_	
				+					
				_	Without mounting option		•	•	
		а	Mounting	B Note 4)	With bracket		•	•	
				Н	With set nut (for panel mount)				
				+			1		
	ote 3)		Float type	— Note 5)	Without auto drain			•	
4	Ž	b	auto drain	C Note 5)	N.C. (Normally closed) Drain port is closed when pressure is not applied.		•		
М	Option Note 3)			D Note 6)	N.O. (Normally open) Drain port is open when pressure is not applied.		_		
	ō			+					
				_	Without pressure gauge		•	•	
		С	Pressure	G	Round type pressure gauge (without limit indicator)	•		_	
			gauge Note 7)		Round type pressure gauge (with limit indicator)			•	•
				M	Round type pressure gauge (with colour zone)	_			
			0-4	+	0.05 to 0.7 MPa setting				
		d	Set pressure Note 8)	1	0.02 to 0.2 MPa setting				
	0		pressure	+	0.02 to 0.2 MPa setting				
	dar				Polycarbonate bowl				
A	tan			2	Metal bowl				
6	Semi-standard			6	Nylon bowl				
	Serr	е	Bowl Note 9)	8	Metal bowl with level gauge				
	(0)			C	With bowl guard			Note 10)	Note 10)
				6C	With bowl guard (Nylon bowl)			Note 11)	Note 11)
				90	with bowl guala (hyloti bowl)				



## Filter Regulator Series AW10-A to AW40-A



	\	_					(	D				
				Symbol	Description	Body size						
						10	20	30	40			
				_	With drain cock	•	•	•	•			
			Drain port Note 12)	■ Note 13)	Drain guide 1/8	_	•	_				
		T	Drain port 1818 127	J Note 10/	Drain guide 1/4	_	_	•	•			
				<b>W</b> Note 14)	Drain cock with barb fitting (for ø6 x ø4 nylon tube)	_	_	•	•			
	ard			+								
	Semi-standard	~	Exhaust	_	Relieving type	•	•	•	•			
<b>5</b>	sta	g	mechanism	N	Non-relieving type	•	•	•	•			
	Ē			+								
	Se	h	Flow direction	_	Flow direction: Left to right	•	•	•	•			
		n	Flow direction	R	Flow direction: Right to left	•	•	•	•			
				+								
		i	Pressure unit	_	Name plate, caution plate for bowl, and pressure gauge in imperial units: MPa	•	•	•	•			
		1	Pressure unit	<b>Z</b> Note 15)	Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F	O Note 16)	O Note 16)	O Note 16)	O Note 16)			

- Note 1) Drain guide is NPT1/8 (applicable to the AW20-A) and NPT1/4 (applicable to the AW30-A to AW40-A). The auto drain port comes with ø3/8" One-touch fitting (applicable to the AW30-A to AW40-A).
- Note 2) Drain guide is G1/8 (applicable to the AW20-A) and G1/4 (applicable to the AW30-A to AW40-A).
- Note 3) Option B, G, H, M are not assembled and supplied loose at the time of shipment.
- Note 4) Assembly of a bracket and set nuts
- Note 5) When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.
- Note 6) If the compressor is small (0.75 kW, discharge flow is less than 100 L/min[ANR]), air leakage from the drain cock may occur during start of operations.
- N.C. type is recommended. Note 7) When the pressure gauge is attached, a 1.0 MPa pressure gauge will be fitted for standard (0.7 MPa) type. 0.4 MPa pressure gauge for 0.2 MPa type (1.0 MPa pressure gauge only
- for the AW10-A). Note 8) Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.
- Note 9) Refer to Chemical data on page 76 for chemical resistance of the bowl.
- Note 10) A bowl guard is provided as standard equipment (polycarbonate).

- Note 11) A bowl guard is provided as standard equipment (nylon).
- Note 12) The combination of float type auto drain: C and D is not available.
- Note 13) Without a valve function
- Note 14) The combination of metal bowl: 2 and 8 is not available.
- Note 15) For pipe thread type: NPT. Cannot be used with M: Round pressure gauge (with colour zone). Available by request for special.
- Note 16) O: For pipe thread type: M5, NPT only

#### **Standard Specifications**

Model	AW10-A	AW20-A	AW30-A	AW40-A	AW40-06-A						
Port size	M5 x 0.8	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4						
Pressure gauge port size	1/16 Note)		1	/8							
Fluid			Air								
Ambient and fluid temperature	−5 to 60°C (with no freezing)										
Proof pressure	1.5 MPa										
Maximum operating pressure	1.0 MPa										
Set pressure range			0.05 to 0.7 MPa								
Nominal filtration rating			5 μm								
Drain capacity (cm³)	2.5	8	8 25 45								
Bowl material			Polycarbonate								
Bowl guard	_	Semi-standard (Steel)	S	tandard (Polycarbonat	e)						
Construction			Relieving type								
Weight [kg]	0.09	0.21	0.41	0.75	0.81						

Note) Use a bushing (part no: 131368) when connecting the R1/8 pressure gauge to the Rc1/16.



## Series AW10-A to AW40-A

#### Options/Part No.

	Ontional anacifica	stiono	Model									
	Optional specifica	uions	AW10-A	AW20-A	AW30-A	AW40-A	AW40-06-A					
Bracket as	ssembly Note 1)		AR12P-270AS	AR22P-270AS	AR32P-270AS	R32P-270AS AR42P-270AS						
Set nut			AR12P-260S	AR22P-260S	AR32P-260S	AR42P-260S						
	Dound type	Standard	G27-10-R1	G36-1	0-□01	G46-1	0-□01					
Pressure Note 2)	Round type	0.02 to 0.2 MPa setting	G27-10-R1 Note 3)	G36-4	1-□01	G46-4-□01						
gauge	Round type	Standard	_	G36-10	)-□01-L	G46-10	-□01-L					
	(with colour zone)	0.02 to 0.2 MPa setting	_	G36-4-	-□01-L	G46-4-□01-L						

Note 1) Assembly of a bracket and set nuts

#### Bowl Assembly/Part No.

Donal	Drain					Model		
Bowl material	discharge mechanism	Drain port	Other	AW10-A	AW20-A	AW30-A	AW40-A	AW40-06-A
		With drain cock	_	C1SF-A	C2SF-A	_	<del>_</del>	
	Manage	With drain cock	With bowl guard	_	C2SF-C-A	C3SF-A	C4S	F-A
	Manual discharge	Drain cock with barb fitting	With bowl guard	_	_	C3SF-W-A	C4SF	-W-A
Polycarbonate	discriarge	With drain guide	_	_	C2SF□-J-A	_	_	_
bowl		(without valve function)	With bowl guard	_	C2SF□-CJ-A	C3SF□-J-A	C4SF	□-J-A
	Automatic	Normally closed (N.C.)	_	AD17-A	AD27-A	_	_	_
	discharge Note)	Normally closed (N.C.)	With bowl guard	_	AD27-C-A	AD37□-A	AD47	′□-A
	(Auto drain)	Normally open (N.O.)	With bowl guard	_	_	AD38□-A	AD48	B□-A
		With drain cock	_	C1SF-6-A	C2SF-6-A	_	_	_
	Manual discharge	Willi dialii cock	With bowl guard	_	C2SF-6C-A	C3SF-6-A	C4SF-6-A	
		Drain cock with barb fitting	With bowl guard	_	_	C3SF-6W-A	C4SF-	6W-A
Nylon bowl		With drain guide	_	_	C2SF□-6J-A	_	_	
INVIOLI DOWL		(without valve function)	With bowl guard	_	C2SF□-6CJ-A	C3SF□-6J-A	C4SF	∃-6J-A
	Automatic	Normally closed (N.C.)	_	AD17-6-A	AD27-6-A	_	_	
	discharge Note)	Normally closed (N.C.)	With bowl guard	_	AD27-6C-A	AD37□-6-A	AD47[	⊒-6-A
	(Auto drain)	Normally open (N.O.)	With bowl guard	_	_	AD38□-6-A	AD48[	□-6-A
		With drain cock	_	C1SF-2-A	C2SF-2-A	C3SF-2-A	C4SF	-2-A
	Manual	Willi dialii cock	With level gauge	_	_	C3LF-8-A	C4LF	-8-A
	discharge	With drain guide	_	_	C2SF□-2J-A	C3SF□-2J-A	C4SF	∃-2J-A
Metal bowl		(without valve function)	With level gauge	_	_	C3LF□-8J-A	C4LF	]-8J-A
IVICIAI DOWI	A	Normally closed (N.C.)	_	AD17-2-A	AD27-2-A	AD37□-2-A	AD47	□-2-A
	Automatic discharge Note)	Two many closed (14.0.)	With level gauge	_	_	AD37□-8-A	AD47	
	(Auto drain)	Normally open (N.O.)	_	_	_	AD38□-2-A	AD48□-2-A	
	( ) ===================================	Normally open (N.O.)	With level gauge		_	AD38□-8-A	AD48[	□-8-A

Note) Minimum operating pressure: N.O. type-0.1 MPa (AD38-A, AD48-A); N.C. type-0.1 MPa (AD17-A, AD27-A) and 0.15 MPa (AD37-A, AD47-A). Bowl assembly for the AW10-A to AW40-06-A models comes with a bowl seal.



Note 2) ☐ in round pressure gauge part numbers indicates a pipe thread type. No indication is necessary for R; however, indicate N for NPT. Please contact SMC regarding the pipe thread type NPT and the supply of pressure gauge with psi unit display specifications.

Note 3) Standard pressure gauge

in bowl assembly part numbers indicates a pipe thread type (applicable tubing for auto drain).

No indication is necessary for Rc thread; however, indicate N for NPT thread, and F for G thread. (For auto drain, —: ø10, N: ø3/8") Please consult with SMC separately for psi and °F unit display specifications.

## $\Delta$ Specific Product Precautions

I Be sure to read this before handling. Refer to the back cover for Safety Instructions, "Handling Precautions for I SMC Products" and the Operation Manual for F.R.L. Precautions, http://www.smc.eu

#### **Design/Selection**

## **∕**∿ Warning

- 1. Although exhaust of the residual pressure to the inlet side is possible when eliminating the inlet pressure, exhaust is not possible when the set pressure is 0.15 MPa or less. Use the regulator with backflow function.
- 2. The standard bowl for the air filter, filter regulator, and lubricator, as well as the sight dome for the lubricator are made of polycarbonate. Do not use in an environment where they are exposed to or come in contact with organic solvents, chemicals, cutting oil, synthetic oil, alkali, and thread lock solutions.

Effects of atmosphere of organic solvents and chemicals, and where these elements are likely to adhere to the equipment. Chemical data for substances causing degradation (Reference)

Type	Chemical name	Application examples	Material			
Туре	GHEITHGAI HAIME	Application examples	Polycarbonate	Nylon		
Acid	Hydrochloric acid Sulfuric acid, Phosphoric acid Chromic acid	Acid washing liquid for metals	Δ	×		
Alkaline	Sodium hydroxide (Caustic soda) Potash Calcium hydroxide (Slack lime) Ammonia water Carbonate of soda	Degreasing of metals Industrial salts Water-soluble cutting oil	×	0		
Inorganic salts	Sodium sulfide Sulfate of potash Sulfate of soda	_	×	Δ		
Chlorine solvents	Carbon tetrachloride Chloroform Ethylene chloride Methylene chloride	Cleansing liquid for metals Printing ink Dilution	×	Δ		
Aromatic series	Benzene Toluene Paint thinner	Coatings Dry cleaning	×	Δ		
Ketone	Acetone Methyl ethyl ketone Cyclohexane	Photographic film Dry cleaning Textile industries	×	×		
Alcohol	Ethyl alcohol IPA Methyl alcohol	Antifreeze Adhesives	Δ	×		
Oil	Gasoline Kerosene	_	×	0		
Ester	Phthalic acid dimethyl Phthalic acid diethyl Acetic acid	Synthetic oil Anti-rust additives	×	0		
Ether	Methyl ether Ethyl ether	Brake oil additives	×	0		
Amino	Methyl amino	Cutting oil Brake oil additives Rubber accelerator	×	×		
Others	_	×	Δ			

When the above factors are present, or there is some doubt, use a metal bowl for safety.

#### Maintenance

## \land Warning

1. Replace the element every 2 years or when the pressure drop becomes 0.1 MPa, whichever comes first, to prevent damage to the element.

#### Mounting/Adjustment

### 🕂 Warning

- 1. Set the regulator while verifying the displayed values of the inlet and outlet pressure gauges. Turning the regulator knob excessively can cause damage to the internal parts.
- 2. Do not use tools on the pressure regulator knob as this may cause damage. It must be operated manually.

### **∖** Caution

- 1. Be sure to unlock the knob before adjusting the pressure and lock it after setting the pressure. Failure to follow this procedure can cause damage to the knob and the outlet pressure may fluctuate.
  - Pull the pressure regulator knob to unlock. (You can visually verify this with the "orange mark" that appears in the gap.)
  - · Push the pressure regulator knob to lock. When the knob is not easily locked, turn it left and right a little and then push it (when the knob is locked, the "orange mark", i.e., the gap will disappear).
- 2. Pulsation will be generated when the difference between the inlet and the outlet pressure is large. In this case, reduce the pressure difference between the inlet and the outlet. Please consult with SMC if the pulsation problem is not resolved
- 3. When the bowl is installed on the AW30-A/AW40-A, install them so that the lock button lines up to the groove of the front (or the back) of the body to avoid drop or damage of the bowl.










## Series AW10-A to AW40-A


#### Flow-rate Characteristics (Representative values)


Condition: Inlet pressure 0.7 MPa














#### Pressure Characteristics (Representative values)


Conditions: Inlet pressure 0.7 MPa, Outlet pressure 0.2 MPa, Flow rate 20 L/min (ANR)







#### AW40-A/AW40-06-A




## Filter Regulator Series AW10-A to AW40-A


#### Construction


#### **AW10-A**

#### **AW20-A**

#### AW30-A to AW40-06-A







#### **Component Parts**

No.	Description	Material	Model	Colour		
4	Body	Zinc die-cast	AW10-A	White		
'	Войу	Aluminum die-cast	AW20-A to AW40-06-A	vvriite		
2	Bonnet	Polyacetal	AW10-A to AW40-06-A	White		

#### **Replacement Parts**


No.	Description	Material	Part no.										
INO.	Description	Material	AW10-A	AW20-A	AW30-A	AW40-A	AW40-06-A						
3	Valve assembly	Stainless steel, HNBR	AR10P-090S	AW22P-060AS	AW32P-060AS	AW42P	-060AS						
4	Filter element	Non-woven fabric	AF10P-060S	AF20P-060S	AF30P-060S	AF40F	P-060S						
5	Diaphragm assembly	Weatherable NBR	AR10P-150AS Note 1)	AR22P-150AS	AR32P-150AS	AR42P	-150AS						
6	Bowl seal	NBR	C1SFP-260S	C2SFP-260S	C32FP-260S	C42FF	P-260S						
7	Bowl assembly Note 2)	Polycarbonate	C1SF-A	C2SF-A	C3SF-A	C45	SF-A						


Note 1) The AW10-A is a piston type. Assembly of a piston and a seal (KSYP-13).

Note 2) Bowl seal is included for the AW20-A to AW40-06-A. Please contact SMC regarding the supply of bowl assembly with psi and °F unit display specifications.

## Series AW10-A to AW40-A

#### **Dimensions**






Applicable model			AW	V30-A to AW40-06-A				
Optional/Semi-standard specifications	Metal bowl	Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide	With drain guide	Drain cock with barb fitting		
Dimensions	B	Width across flats 17	a	Width across flats 17	Width across flats 17	Barb fitting applicable tubing: T0604		

				C+	andard sp	ooifiootio	no.				Optional specifications					
Model				316	anuaru sp	ecincano	1115				Round type pressure gauge Round type pressure gauge (with colour					
	P1	P1											Н	J		
AW10-A	M5 x 0.8	1/16	25	59.9	47.4	12.5	_	M18 x 1	25	12.5	ø26	26	_	_		
AW20-A	1/8, 1/4	1/8	40	87.6	67.4	22	_	M36 x 1.5	25	22	ø37.5	58.5	ø37.5	59.5		
AW30-A	1/4, 3/8	1/8	53	115.1	83.5	28.5	30	M45 x 1.5	35	28.5	ø37.5	65	ø37.5	66		
AW40-A	1/4, 3/8, 1/2	1/8	70	147.1	100	34.5	38.4	M52 x 1.5	40	34.5	ø42.5	72	ø42.5	72		
AW40-06-A	3/4	1/8	75	149.1	101.5	34.5	38.4	M52 x 1.5	40	34.5	ø42.5	72	ø42.5	72		

					Opti	onals	specifi	cation	ıs				Semi-standard specifications					
Model			Brac	ket m	ount			Panel mount Wi				With auto drain	With barb fitting	With drain guide	Metal bowl	Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide
	M N Q R S T U					U	٧	W	Υ	Z	В	В	В	В	В	В	В	
AW10-A	25	28	30	4.5	6.5	40	2	18	18.5	_	_	77.9	_	_	59.3	_	_	_
AW20-A	30	34	43.9	5.4	15.4	55	2.3	27.3	36.5	17.5	6	104.9	_	91.4	87.4	93.9	_	_
AW30-A	41	36	46	6.5	24	65	2.3	32.5	45.5	22.5	7	156.8	123.6	121.9	117.6	122.1	137.6	142.1
AW40-A	50	38	54	8.5	26.5	70	2.3	38.4	52.5	26	7	186.9	155.6	153.9	149.6	154.1	169.6	174.1
AW40-06-A	50	38	55.5	8.5	26.5	70	2.3	39.9	52.5	26	7	188.9	157.6	155.9	151.6	156.1	171.6	176.1





# Filter Regulator/AW20-A to AW40-06-A Made to Order





#### 1 0.4 MPa Setting

The maximum set pressure is 0.4 MPa. When a pressure gauge is included, the display will show a range from 0 to 0.7 MPa.

#### **Specifications**

Proof pressure	1.5 MPa
Maximum operating pressure	1.0 MPa
Set pressure range	0.05 to 0.4 MPa

#### **Applicable Model**

Model	AW20-A	AW30-A	AW40-A	AW40-06-A
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4

#### 2 Long Bowl


Drain capacity is greater than that of standard models.

#### **Applicable Model/Drain Capacity**

Model	AW20-A	AW30-A	AW40-A	AW40-06-A		
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4		
Drain capacity (cm <sup>3</sup> )	19	43	88			

Note) Please consult with SMC for dimensions.

#### **How to Order**



• Option	Semi-	standard: Select one ea standard symbol: When V30-03BG- <u>2N</u> -A-X4	more than	one specification is required, indicate in alphanumeric order.	0.4 [	MPa Set	ting	L	ong Bo	wl
	_					0			0	
			Symbol	Description		Body size			Body size	
					20	30	40	20	30	40
			_	Rc	•	•	•		•	•
2	Pip	e thread type	N Note 1)	NPT	•	•	•	•	•	•
			F Note 2)	G	•	•	•		•	•
			+							
			01	1/8	•	_	_		_	_
	Port size		02	1/4	•	•	•	•	•	•
3			03	3/8	_	•	•	_	•	•
			04	1/2	_	_		_	_	•
			06	3/4	_	_	•	_	_	•
			+							
			_	Without mounting option						
	а	Mounting	<b>B</b> Note 4)	With bracket						•
			Н	With set nut (for panel mount)						
9			+							
Note (			_	Without auto drain				_	_	_
4 Option Note	b	Float type auto drain	C Note 5)	Float type auto drain (N.C.)				_	_	_
) jtj		auto diani	D Note 6)	Float type auto drain (N.O.)	_				_	_
			+							
			_	Without pressure gauge						•
	С	Pressure gauge	G	Round type pressure gauge (with limit indicator)				Note 7)	Note 7)	Note
			M	Round type pressure gauge (with colour zone)				Note 7)	Note 7)	Note

Note 1) Drain guide is NPT1/8 (applicable to the AW20-A) and NPT1/4 (applicable to the AW30-A to AW40-A).

The auto drain port comes with ø3/8" One-touch fitting (applicable to the AW30-A to AW40-A).

Note 2) Drain guide is G1/8 (applicable to the AW20-A) and G1/4 (applicable to the AW30-A to AW40-A)

Note 3) Option B, G, H, M are not assembled and supplied loose at the time of shipment. Note 4) Assembly of a bracket and set nuts

Note 5) When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl.

Releasing the residual condensate before ending operations for the day is recommended.

Note 6) If the compressor is small (0.75 kW, discharge flow is less than 100 L/min[ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended.

Note 7) When the pressure gauge is attached, a 1.0 MPa pressure gauge will be fitted for standard (0.7 MPa) type. 0.4 MPa pressure gauge for 0.2 MPa type.



AF+AR+AL

AW+AL

AF+AR

AF+AFM+AR

						0.4	MPa Set	tting	L	ong Bo	wl
	_	_		Symbol	Description		1 Body size			1 Body size	
						20	30	40	20	30	40
		d	Set	_	0.05 to 0.7 MPa setting	_	_	_		•	•
		a	pressure Note 8)	1	0.02 to 0.2 MPa setting	_	_	_		•	•
				+							
			Bowl Note 9)	_	Polycarbonate bowl						
				2	Metal bowl						
				6	Nylon bowl						
		е	DOMI More a)	8	Metal bowl with level gauge	_			_	_	_
				С	With bowl guard	•	_	_		Note 11)	Note 11)
				6C	With bowl guard (Nylon bowl)		_	_		Note 12)	Note 12)
	ard In										
	Semi-standard			_	With drain cock		•			•	
6	sta	f	Note 10)  Drain port	. ■ Note 13)	Drain guide 1/8	•	_	_		_	_
	Ë	'	Diain port	J,	Drain guide 1/4	_	•	•	_	•	•
	Se			<b>W</b> Note 14)	Drain cock with barb fitting (for ø6 x ø4 nylon tube)	_	•		_	•	
		+									
		~	Exhaust	_	Relieving type		•			•	
		g	mechanism	N	Non-relieving type						
				+							
		h	Flow direction	_	Flow direction: Left to right						
		n	riow direction	R	Flow direction: Right to left	•	•	•		•	•
				+							
		i	Proceure unit	_	Name plate and caution plate for bowl in imperial units: MPa		•			•	•
		'	Pressure unit	<b>Z</b> Note 15)	Name plate and caution plate for bowl in imperial units: psi, °F	Note 16)	Note 16)	Note 16)	Note 16)	Note 16)	Note 16)

Note 8) Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.

Note 9) Refer to Chemical data on page 76 for chemical resistance of the bowl.

Note 10) The combination of float type auto drain: C and D is not available. Note 11) A bowl guard is provided as standard equipment (polycarbonate). Note 12) A bowl guard is provided as standard equipment (nylon).

Note 13) Without a valve function

Note 14) The combination of metal bowl: 2 and 8 is not available.

Note 15) For pipe thread type: NPT.
Cannot be used with M: Round pressure gauge (with colour zone). Available by request for special.

Note 16) O: For pipe thread type: NPT only



## Filter Regulator/AW20-A to AW40-06-A

## **Made to Order**



Please contact SMC for detailed dimensions, specifications and lead times.

#### 3 0.85 MPa Setting

The maximum set pressure is 0.85 MPa. When a pressure gauge is included, the display will show a range from 0 to 1.0 MPa.


#### **Specifications**

Proof pressure	1.5 MPa
Maximum operating pressure	1.0 MPa
Set pressure range	0.05 to 0.85 MPa

#### **Applicable Model**

Model	AW20-A	AW30-A	AW40-A	AW40-06-A
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4

#### **How to Order**



- · Option/Semi-standard: Select one each for a to i.
- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order Example) AW30-03BG-2N-A-X2068

#### 0.85 MPa Setting

		,								
	_	_		Coursels al	Description		0			
					Symbol   Description		Body size			
						20	30	40		
				_	Rc	•	•			
2	2 Pipe thread type			N Note 1)	NPT					
				F Note 2)	G		•	•		
				+						
				01	1/8		_	_		
				02	1/4	•				
3			Port size	03	3/8	_				
				04	1/2	_	_			
					3/4	_	_	•		
				+						
		а	Mounting		Without mounting option					
				<b>B</b> Note 4)	With bracket					
				Н	With set nut (for panel mount)					
	<sub>€</sub>			+						
	Option Note 3)		Flack to an a	_	Without auto drain	•				
4	l o	b	Float type auto drain	C Note 5)	Float type auto drain (N.C.)	•				
	) tid		auto drain	D Note 6)	Float type auto drain (N.O.)	_	•			
				+						
				_	Without pressure gauge	•	•			
		С	Pressure gauge	G	Round type pressure gauge (with limit indicator)					
				M	Round type pressure gauge (with colour zone)					

Note 1) Drain guide is NPT1/8 (applicable to the AW20-A) and NPT1/4 (applicable to the AW30-A to AW40-A). The auto drain port comes with ø3/8" One-touch fitting (applicable to the AW30-A to AW40-A).

Note 2) Drain guide is G1/8 (applicable to the AW20-A) and G1/4 (applicable to the AW30-A to AW40-A). Note 3) Option B, G, H, M are not assembled and supplied loose at the time of shipment.

Note 4) Assembly of a bracket and set nuts

Note 5) When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl.

Releasing the residual condensate before ending operations for the day is recommended.

Note 6) If the compressor is small (0.75 kW, discharge flow is less than 100 L/min[ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended.



#### 0.85 MPa Setting

	_	_					0		
				Symbol Description		Body size			
						30	40		
					Polycarbonate bowl				
				2	Metal bowl				
		d	Bowl Note 7)	6	Nylon bowl				
		u	DOWI Note 77	8	Metal bowl with level gauge	_			
				С	With bowl guard	•	_	_	
				6C	With bowl guard (Nylon bowl)	•	_	_	
				+					
	Semi-standard			_	With drain cock		•		
		е	Drain port	J Note 9)	Drain guide 1/8	•	_	_	
6		-	Dialii port		Drain guide 1/4	_			
•	j-S-l			<b>W</b> Note 10)	Drain cock with barb fitting (for ø6 x ø4 nylon tube)	_			
	) Seri			+					
	0)		f	Exhaust	_	Relieving type		•	
		•	mechanism	N	Non-relieving type				
				+					
		_	Flow direction	_	Flow direction: Left to right				
		g	Flow direction	R	Flow direction: Right to left	•	•		
				+					
		h	Pressure unit	_	Name plate and caution plate for bowl in imperial units: MPa				
		n	Pressure unit	<b>Z</b> Note 11)	Name plate and caution plate for bowl in imperial units: psi, °F	Note 12)	Note 12)	Note 12)	
Milete	-, -		01	== (	ala analisad was interess of the descrip				

Note 7) Refer to Chemical data on page 76 for chemical resistance of the bowl. Note 8) The combination of float type auto drain: C and D is not available.

Note 9) Without a valve function

Note 10) The combination of metal bowl: 2 and 8 is not available.

Note 11) For pipe thread type: NPT.

Cannot be used with M: Round pressure gauge (with colour zone). Available by request for special. Note 12) O: For pipe thread type: NPT only

#### 4 Non-standard filtration rating

